Alarm and Flash function command guide

1. Cut With Alarm And Flash

Command (Hex): 1F 1B 1F E0 13 14 m n t mode m = 00/01, OFF/ON n: 1<=n<=20, times of alarm and flash. t: 1<=n<=20, The alarm and flashing interval, it is t x 50ms. Mode = 00/01/02/03,

00: No alarm, no flash; 01: Only alarm, no flash; 02: Only flash, no alarm; 03: Alarm and flash.

Sample: Turn on cut with alarm and flash, four times, interval is 100ms: 1F 1B 1F E0 13 14 01 04 02 03. Turn off cut with alarm and flash: 1F 1B 1F E0 13 14 00 04 02 03.

2. Ticket Taken Alarm

After cutting if don't take away the ticket within a specified time, printer alarm and flash feature. **Command(Hex):** 1F 1B 1F A0 mode toh tol aoh aol

MODE = 00/01/02

00: Trun off; 01: Affter cutting, start the timer; 02: If don't take away the ticket, and have a new ticket and cutting(second cutting), alarm and flash

immediately without waiting.

TOH TOL: Ticket taken alarm timeout, unit is **seconds**, default is **10s**. If you set 0s, alarm and flash immediately without waiting.

AOH AOL: Alarm and flash timeout, unit is **seconds**, default is **300s**. If you set 0s, no timeout, printer alarm and flash until take away the ticket.

Sample: Trun off: 1F 1B 1F A0 00 00 05 00 05 Alarm after 5 seconds: 1F 1B 1F A0 01 00 05 00 05 Alarm after 10 seconds: 1F 1B 1F A0 01 00 0A 00 05

How to use it?

Please download the setting tool here: https://cdn-point.de/shared-media-files/downloads/tools/Printer-TEST-V31C-pxd61006.zip

